

List of components

Valid for all LPE pumps, size 025/032/038. Rotor lead and Generation: D3/K3/L3/N3

With version codes: N} V} B} P} The version code is composed of the letters in the 4 columns.
T} Y} Example of pump designations std: LPE 025L3 NTBP;
option: LPE 038N3 NVBP

| PosNo | Designation | Qty | Components included in spare parts set | | | | | Notes |
|-------|----------------------------|-----|--|------|------|------|------|-------|
| | | | G012 | G050 | G053 | G054 | G057 | |
| 1020 | Power rotor | 1 | x | | | x | | |
| 113 | Key | 1 | x | | | x | | |
| 122 | Ball bearing | 1 | x | | x | x | | |
| 125 | Secondary seal | 1 | | x | x | x | | 1 |
| 202 | Idler rotor | 2 | x | | | x | | |
| 351 | Balancing bush | 1 | x | | | x | | |
| 401 | Pump body | 1 | | | | | | |
| 416 | Suction flange | 1 | | | | | | |
| 417 | Screw | 8 | | | | | | |
| 418 | Gasket to suction flange | 1 | | | x | x | x | |
| 423 | Gasket to discharge flange | 1 | | | x | x | x | |
| 427 | Discharge flange | 1 | | | | | | |
| 440 | Return valve | 1 | | | | | | 2 |
| 451 | Screw | 4 | | | | | | |
| 453 | Screw | 4 | | | | | | |
| 462 | Plug | 1 | | | | | | |
| 462A | Sealing washer | 1 | | | x | x | x | |
| 463 | Plug | 1 | | | | | | |
| 463A | Sealing washer | 1 | | | x | x | x | |
| 501 | Front cover | 1 | | | | | | |
| 506 | Gasket | 1 | | | x | x | x | |
| 509 | Shaft seal | 1 | | x | x | x | | |
| 537 | Deaeration plug | 2 | | | | | | |
| 537A | Washer | 2 | | | x | x | x | |
| 551 | Rear cover | 1 | | | | | | |
| 556 | Gasket | 1 | | | x | x | x | |
| 557 | Plug | 1 | | | | | | |
| 557A | Washer | 1 | | | x | x | x | |
| 605 | O-ring | 1 | | | x | x | x | x |
| 608 | Valve spindle | 1 | | | | x | | x |
| 608A | Tension pin | 1 | | | | x | | x |
| 6120 | Set screw | 1 | | | | x | | x |
| 613 | Pin | 1 | | | | x | | x |
| 614 | Valve piston | 1 | | | | x | | x |
| 615 | Valve spring | 1 | | | | x | | x |
| (*) | Plug | 1 | | | x | x | x | |
| (*) | Washer | 1 | | | x | x | x | |

Explanations:

G012: Rotor set
G050: Shaft seal
G053: Minor kit
G054: Major kit
G057: Joint kit
G070: Valve element

Notes:

- 1) Version NTxP
- 2) Removed from August 2011

